

JVC**SERVICE MANUAL****FM/AM STEREO TUNER****MODEL T-E30B/T-E30LB**

T-E30B



T-E30LB

Contents

	Page		Page
Safety Precautions	1-1	5. FM/AM/LW Tuner Alignment Procedures	
1. Specifications	1-2	5-(1) Frontend Section	1-7
2. Service Precautions	1-2	5-(2) IF Detection	1-7
3. Block Diagram	1-3	5-(3) MPX Section	1-7
4. Names of Parts and Their Functions	1-4	5-(4) AM Tuner Section	1-7
5. Exploded View and Removal Procedures		5-(5) Signal Indicator	1-7
5-(1) Removal of Top Cover	1-6	7. T-E30B/T-E30LB Schematic Diagram	
5-(2) Removal of Front Panel	1-6	7-(1) T-E30B Tuner Section	Insertion
5-(3) Removal of Tuner P.C.B.	1-6	7-(2) T-E30LB Tuner Section	Insertion
5-(4) Removal of Front P.C.B.	1-6	7-(3) Voltage of Main Points & Power Supply	
5-(5) Removal of Power Supply & FL P.C.B.	1-6	Section	Insertion
		Parts List	Separate volume Insertion
		8. Internal Block Diagrams of Major LSI ICs	1-8