



■ NO. 35260-A AMPLIFIER ASSEMBLY

Item	Part No.	Description	Item	Part No.	Description
1	35354	Output Transformer	20	11578	Pointer Knob
2	35354	Output Transformer	21	31192	Slide Switch (D.P.D.T.)
3	33753	Tube Clamp Spring - Long	22	35126	Amp Lok Plug - 3 Circuit
4	33229	6973 Tube	23	34031	Main Stereo Speaker Terminal Strip
5	33229	6973 Tube	24	11578	Pointer Knob
6	35126	Amp Lok Plug - 3 Circuit	25	35343	3 Pin Socket
7	32852	12 AX7 Tube	26	34069	7800 Ohm 25 Watt Standee Resistor
8	18634	6 Prong Miniature Socket	27	35348	Remote Speaker Terminal Strip
9	33751	Tube Clamp Spring - Short	28	35342	2220 Ohm 25 Watt Standee Resistor
10	33245	Balance Control	29	35365	12 AU7 Tube
11	33752	Tube Clamp Spring - Medium	30	33229	6973 Tube
12	32498	6 CY7 Tube	31	11578	Pointer Knob
13	33207	Tube Shield	32	33229	6973 Tube
14	35365	12 AU7 Tube	33	ST-4332	1 Amp. Slo-Blo Fuse
15	33199	Dual Input Socket	34	32824	Grounded Can Doubler Capacitor
16	35340	Potentiometer - 75 Ohm 1 Watt	35	35340	Potentiometer - 75 Ohm 1 Watt
17	11578	Pointer Knob	36	30316	Filter Capacitor - 4 Section
18	32498	6 CY7 Tube	37	34032	8 Ohm Candohm Resistor
19	35340	Potentiometer - 75 Ohm 1 Watt			