

Marque	Fréquence	Modèle
ADYX	433.9 2	ALIZE EM2C, ALIZE EM4C
AETERNA	433.9 2	TX433 1,2,4 buttons
ALLMATIC	433.9 2	AEMX1, AEMX2, AEMX4
		EUROPE AUTO ARMY2, ARMY1, ARMY4
		MX1, MX2, MX4
ALLTRONIK	433.9 2	S429_1, S429_2, S429_4, S429_M Be sure that your remote operates at 433.92MHz!
		S425
ANSONIC	433.9 2	SA 434-1E, SA434-2E, SA434-3E, SA434-4E
		SA 434-1MINI, SA434-2MINI, SA 434-2Midi
APERTO	433.9 2	CPS1, CPS2, CPS4
AVIDSEN	433.9 2	100601 micromark MM23164
		104505
		100951, 100955, 100550, 100400
BANDY	433.9 2	
BELFOX	433.9 2	DHS433-1, DHS433-2, DHS433-4, dip switch version
		DHS 433,92 (7733), dip switch version
BENINCA'	433.9 2	LOT1W, LOT2W, LOT4W
		LOT2WMS
		T2WK, T4WK
		LOTX1W, LOTX2W, LOTX4W
		TO.GO2WP, TO.GO4WP, TO.GO2WK, TO.GO4WK
BESIDE	433.9 2	BEZAP
		HIT
BFT	433.9 2	TE01, TE02 (TEO1, TEO2)
		TE04 (TEO4)
CAME	433.9 2	T432, T434, TOP432A, TOP434A, TOP432, TOP432NA, TOP434NA

		TOP432M, TOP434M
		TAM432SA
		TOP432SA
		TOP432NA
		TWIN2, TWIN4
CARDIN	433.9 2	S476 TX2, S476TX4
CASALI GENIUS	433.9 2	Genius 433 2, Genius 433 3, JA400 TM433, JA401 TM433
CASIT	433.9 2	ERTS92B, ERTS92T
		ERTS20DB, ERTS20DQ
		ERTS476D, ERTS476Q
		TXS1, TXS2, TXS3, TXS4, TXS6 ERTS97B, ERTS97T
CELINSA	433.9 2	S10 1, S10 2, SAW1, SAW2
CENTURION	433.9 2	CLASSIC, SMART, SMART2
CPS	433.9 2	TCP3, CPS, Jolly 4
		CPS1 TCP3, CPS2 TCP3, CPS4 TCP3 EM1CV, EM2CV, EM4CV
DASPI	433.9 2	Happy2, Pops2Ã,
DEA	433.9 2	433 1, 433 2, 433 4
		Genie
		Punto S2
		Dea MIO TD2, MIO TD4
DELMA	433.9 2	Mizard 433 1, Mizard 433 2
		King 433 2
		Style Copy 2CH (this is a code duplicator)
DICKERT	433.9 2	MAHS433 01, MAHS433 04
		S10-433A1L00, S10-433A4L00, S20-433A1L00, S20-433A4L00, S20-433A1000, S20-433A4000
		S5-433-A2L00, S5U-433-A2L00
DITEC	433.9 2	GOL4C
		GOL4 Note: These transmitters are rolling code and cannot be duplicated, but if you have a GOL4C device, you can duplicate it on ACLUS or

		PANDIS, and it works with all the DITEC receivers.
		BIX LS2, BIX LP2, BIX LG4 Note: These transmitters are rolling code and cannot be duplicated, but if you have a GOL4C device, you can duplicate it on ACLUS or PANDIS, and it works with all the DITEC receivers.
DOITRAND FDOITRAND	433.9 2	MPSTF2E JAUNE, MPSTF4E, HYPERPHONE MPSTF2E_GRISE TS2DE, TS4DE
DOORMATIC	433.9 2	SAW
DUCATI ALLDUCKS	433.9 2	TSAW1, TSAW2, TSAW3, TSAW4, 124 ELBER TSAW1, TSAW2, TSAW3, TSAW4 RONDY TSAW1, RONDY TSAW2, RONDY TSAW3 TPR10-A, TPR20-A RONDY TPR10 A, RONDY TPR20 A TE2 HC6203, 6203: only blue , red and transparent
ELBE	433.9 2	501, 502, 504 502a, 504a 502, 504
ELCA	433.9 2	IRIS, IRIS 9CH. Both colors red and blue ASTER2 Aster 1000, Aster1001. Colors: black, blue, light grey GEMINI 9CH VIRGO
ELVOX	433.9 2	ET03, ET04
ERONE	433.9 2	SETDS39433E2, SETDS39433E4
FAAC	433.9 2	TM1 433 DS, TM2 433 DS, TM3 433 DS

		TML2 433 SLP, TML4 433 SLP, TML2-433-SLP, TML4-433-SLP
FADINI BPT	433.9 2	433 2M, Astro43_2m
		Astro433-2, Astro433-4, Astro43-2, Astro43-4
FERPORT	433.9 2	Tac1, Tac2, Tac4, Tac1k, Tac2k, Tac4k, Tac2kr
GIBIDI	433.9 2	Open TMB 433, OPEN TMQ 433, OPEN OUT 2, OPEN OUT 4
GULLIVER	433.9 2	MDW 2E
HAUSS	433.9 2	Pocket 3750-1, Pocket3750-2, Pocket 3750-4
HORMANN HOERMANN Hörmann	433.9 2	HSM2, HSM4, yellow buttons
HRC	433.9 2	
JAY	433.9 2	UBEI x1 SL1
		UBET 11, UBET 21, UBET 31, UBET 41, UBET 61, UBET 61A,
KING	433.9 2	Note: receiver should be setup with rolling code feature disabled
IUPPITER	433.9 2	RJW/1E, RJW/2E, RJW/4E, RJW/12E
		MDW/1E, MDW/2E
LEB	433.9 2	TMW
		TSAW2N, TSAW4N
		TCP3A, (this is a code duplicator)
		TRK4 Note: receiver should be configured to disable rolling check.
		TPW4
LINCE	433.9 2	LR 2035
MA SYSTEM	433.9 2	MA TX1, MA TX2, MA TX3
MARANTEC	433.9 2	D101
		D12
		D212, D222, D232
		Digital 302, D302

		Digital 304, D304
MEIÄfÅ,NER MEISSNE R	433.9 2	LW433-1, LW433-2, LW433-4 Pocket 3750 1, 2, 4
MONSEIGNEUR	433.9 2	ARC2, ARC4 TDR 400 3845, TDR 400 3846, TDR 400 3847 T1SAW433, T2SAW433, T4SAW433
MOTORLINE STATEUR OP	433.9 2	MX1, MX2, MX3, MX4, MX6 MX11, MX12, MX13
MOTOSTAR	433.9 2	CLIKSTAR2, CLICKSTAR4 CLICK-4M, CLICKSTAR RE 532, CLICKSTAR RE 534
NICE	306 433.9 2	EASY S1, S2, S4 FLO1, FLO2, FLO4 VERY VE
NOLOGO	433.9 2	ECO DIP
OG	433.9 2	OG62, OG64
O&O OeO, O and O	433.9 2	T-COM DS 4-2, T-COM DS 4-4
OPENOUT	433.9 2	TMQ 433 2, TMQ 433 4
PIAZZETTA	433.9 2	4 buttons for wood/pellet heater
PORTAMATIC	433.9 2	MPH01, MPH02
POWERFIX Profi (Lidl)	433.9 2	RCB-A 3600R
PRASTEL	433.9 2	MPSTF2E, MPSTF4E
PROEM	433.9 2	ER2C4ACM, ER4C4ACM
PROGET	433.9 2	ETY_433N2, ETY 433N4 EMI433-N2
PROTECO	433.9 2	TX433 EUROMATIC HIT
QUASAR	433.9 2	433 TANGO SLIM BLEU
SEA	433.9 2	SMART433_TX2_DIP, SMART433_TX3_DIP SMART4

		33_TX2_COPY, SMART433_TX 3_COPY Smart2 Dip Switch, Smart3 Dip Switch
SEAV	433.9 2	TXS1, TXS2, TXS3, TXS4
		Behappy S1, Behappy S2, Behappy S3
		Be Easy TX, Be Easy Murale2
		BeSmart S2, BeSmart S4
		BeFree S1
SECURVERA	433.9 2	SV R2C
		SV R2C
		SV R4C
		SV R6C
SENDER	433.9 2	
SERAI	433.9 2	OG/52, OG/54, OG/82, OG/84
		OG/28, OG/48, OG/62, OG/64
		OG/02, OG/04
SICE	433.9 2	TX4 CLACK Bigfoot
SIMINOR	433.9 2	ER2C4ACM, ER4C4ACM, ER2C4ACS, ER4C4ACS
SMD	433.9 2	LW433-1, LW433-2, LW433-4 : AM models only
SOMFY	433.9 2	LEB TMW
STAGNOLI	433.9 2	ZEUS AZTR
STARTEC	433.9 2	TXQ2
TAU	433.9 2	250 SLIM, 250K-SLIM, 250K- SLIMC
		250TXD2, 250TXD4
		250BUG2, 250BUG4
		250T-4, 250T-4C
TECNOMATIC	433.9 2	TQ433
TEDSEN	433.9 2	SKX1MD, SKX2MD, SKX3MD, SKX4MD
BERNER		SKX1KD, SKX2KD, SKX4KD, SKX6KD
GFA		SKX1DL, SKX2DL, SKX3DL,

		SKX4DL
		SKX1LC, SKX2LC, SKX3LC, SKX4LC
		SKX1SL, SKX2SL, SKX3SL, SKX4SL
		SKJ
		SKX1WD, SKX2WD, SKX4WD, SKX11WD, SKX22WD, SKX44WD
TELCOMA	433.9 2	TANGO 2 SW, TANGO4 SW
		TANGO BLUE 2, TANGO 4 BLUE, TANGO BLEU 2, TANGO BLEU 4
		TANGO 2 SLIM, TANGO 4 SLIM
		TANGO WIN3
		TANGO2, TANGO4
TKC	433.9 2	TSAW433
TORAG	433.9 2	S429 1, S429 2, S429 4
TORMATIC	433.9 2	HS, Dorma HS43 1E, HS43 2E, HS43 3E, HS43 4E
DORMA		MAHS, Siebau, Novoferm, Dorma
		MHS, MHS43-1
TREMA	433.9 2	TO93TV1, TO93TV2, TO93TV4
TUBAUTO	433.9 2	DIGITAL 101 433
V2	433.9 2	PHOENIX series: Phoenix2, Phoenix2P, Phoenix4, Phoenix4P. Note:the receiver should be programmed with the rolling code feature disabled. When the code is learned, LED will blink for 6 times to highlight that the code is rolling.
		TCP3
		TCP3, ARC3
		TCP3
		TPR

		T1SAW/433, T2SAW/433, T4SAW/433
		TRR1, TRR2, TRR4
		PMR2, PMR4
VISONIC	433.9 2	WT 100, WT 100A, WT 101, WT 101A, WT 102, WT 104, WT 201, WT 201A, WT 201WP, WT 201AWP
VSEG	433.9 2	CR SLIM
WAINE-DALTON	433.9 2	S429-1, S429-2, S429-4, S429- mini
		S425
WECLA CDS	433.9 2	433, 433_2