




A SHOWS CORRECT STRINGING WITH GANG P 4975
 B SHOWS CORRECT STRINGING WITH GANG 68A2




7




8




9










10



11







To string dial cord, turn the main drive drum to maximum counter-clockwise position

