
TR1
AC126
TR2
AC126
TR3
AC126
TR4
AC126
TR5
AC128
TR6
AC128
TR7
AC126
MOD LEVEL CONT
VOL CONT
BATTERY & MOD LEVEL IND
SW SHOWN IN OFF POS
SW3
LS1
7·5V
BU1
MIC IN/P, RADIO & GRAM IN/P
(VIA CONN LEAD), LINE O/P
BU2
REMOTE STOP/START CONT
& EXT MAINS SUPPLY UNIT IN/P
H'PHONE O/P